













**Single Pole Switch**  
BR - White

The **3700 Series** is the **versatile option** for installations in **professional** or **institutional spaces** like offices, schools, commerce, etc.









With a **discreet design**, the **3700 Series** can be applied alone in **surface mounting installations** and together with the **10 Series of Cable-trunkings for Electrical and Telecommunications Installations**.

It is available in **White** colour (RAL 9003) and it has a wide range of functions with 38 basic functions.





### CONTROL DEVICES

		Ref.	Colour	Box (Un)
	Single Pole Switch 10AX - 250V~	37011 C	BR	10
	Single Pole Switch with Orienting Light 10AX - 250V~ ■ To control electronic energy-saving lamps, we recommend the use of capacitors of 0,15μF 275V~ connected in parallel to the load to avoid the blinking in the lamp when the contact is open.	37012 C	BR	10
	Single Pole Switch with Pilot Lamp 10AX - 250V~	37013 C	BR	10
	Two Circuits Switch 10AX - 250V~	37061 C	BR	10
	Two-way Switch 10AX - 250V~	37071 C	BR	10
	Two-way Switch with Orienting Light 10AX - 250V~ ■ To control electronic energy-saving lamps, we recommend the use of capacitors of 0,15μF 275V~ connected in parallel to the load to avoid the blinking in the lamp when the contact is open.	37072 C	BR	10
	Two-way Switch with Pilot Lamp 10AX - 250V~	37073 C	BR	10
	Double Two-way Switch 10AX - 250V~	37101 C	BR	10





## CONTROL DEVICES

		Ref.	Colour	Box (Un)
	Intermediate Switch 10A - 250V~	37051 C	BR	10
	Rocker Push-button Switch 10A - 250V~	37151 C	BR	10
	Rocker Push-button Switch with Orienting Light 10A - 250V~	37152 C	BR	10
	Push-button Switch 10A - 250V~	37157 C	BR	10
	Push-button Switch with Orienting Light (250V) 2A - 250V~	37158 C	BR	10
	Push-button Switch with Orienting Light (12V) 6A - 12V	37168 C	BR	10
	Venetian Switch 10A - 250V~ <ul style="list-style-type: none"> <li>■ Switch function.</li> <li>■ Electrical and Mechanical Blockade against the appearance of two simultaneous orders.</li> <li>■ Toggles automatically one rocker when the other is pressed.</li> </ul>	37290 C	BR	10
	Venetian Double Push-button 10A - 250V~ <ul style="list-style-type: none"> <li>■ Push-button function.</li> <li>■ Electrical and Mechanical Blockade against the appearance of two simultaneous orders.</li> </ul>	37281 C	BR	10

### DATA SOCKETS

		Ref.	Colour	Box (Un)
	Single RJ45 Cat. 6 UTP Computer Socket	37455 C	BR	10
	Single RJ45 Cat. 6 STP Computer Socket	37445 C	BR	10
	Single RJ45 Cat. 5e UTP Computer Socket	37453 C	BR	10
	Single RJ45 Cat. 5e STP Computer Socket	37443 C	BR	10

### TELEPHONE SOCKETS

		Ref.	Colour	Box (Un)
50V $\sim$ 70V ~				
	Telephone Socket (RITA)	37251 C	BR	10
	Telephone Socket (4 Conductors)	37252 C	BR	10
	Telephone Socket (6 Conductors)	37253 C	BR	10
8 contacts				
	T8 French Telephone Socket	37411 C	BR	10

RADIO, TELEVISION AND SATELLITE SOCKETS				
		Ref.	Colour	Box (Un)
Radio and Television Sockets				
	<p>Equalized R - TV Socket for Star Connection (Terminal Type)</p> <ul style="list-style-type: none"><li>■ Coaxial Connector ø 9,5.</li><li>■ 4 - 862 MHz.</li><li>■ Insertion Losses: ≤ 0,5dB.</li></ul>	37531 C	BR	10
	<p>Equalized R - TV Socket for Series Connection (Crossover Type)</p> <ul style="list-style-type: none"><li>■ Coaxial Connector ø 9,5.</li><li>■ 4 - 862 MHz.</li><li>■ Insertion Losses: ≤ 6dB.</li><li>■ Flow: ≤ 2dB.</li></ul>	37532 C	BR	10
Radio, Television and Satellite Sockets				
	<p>R TV - SAT Socket for Star Connection</p> <ul style="list-style-type: none"><li>■ Coaxial Connector ø 9,5.</li><li>■ 4 - 470 MHz.</li><li>■ Insertion Losses: ≤ 1dB.</li><li>■ 470 - 822 MHz.</li><li>■ Insertion Losses: ≤ 2dB.</li><li>■ 822 - 862 MHz.</li><li>■ Insertion Losses: ≤ 6dB.</li><li>■ Current Flow: 500mA.</li></ul>	37550 C	BR	10
	<p>Coaxial F Computer Socket</p>	37431 C	BR	1












### ENERGY SOCKETS

		Ref.	Colour	Box (Un)
	Safety Earth Socket (Schuko Type) 16A - 250V~	37132 C	BR LR VM	10
	Earth Socket (Schuko Type) 16A - 250V~	37131 C	BR LR VM	10
	Safety Single Phase Socket 16A - 250V~	37122 C	BR	10
	Single Phase Socket 16A - 250V~	37121 C	BR	10
	Safety Earth Socket (French Type) 16A - 250V~	37112 C	BR	10
	Earth Socket (French Type) 16A - 250V~	37111 C	BR	10

### OTHER PRODUCTS

		Ref.	Colour	Box (Un)
	Wall Rose ■ Without Connectors.	37170 C	BR	10
	Junction Box ■ 4x2,5mm <sup>2</sup> .	37201 C	BR	10
	Pilot Light ■ Max. 5W / 250V~ (E14). ■ To be used with Lamp Ref. 81012 (page 158).	37360 C	BI BJ BV BM	2
	Stereo Music Socket ■ Connector DIN 41529.	37221 C	BR	10

## ADAPTERS FOR 10 SERIES CABLE-TRUNKINGS

		Ref.	Colour	Box (Un)
	3700 Series Adapter for <b>12x7</b> Trunking	10017 A	BR	20
	3700 Series Adapter for <b>16x10</b> Trunking	10027 A	BR	20
	3700 Series Adapter for <b>20x12,5</b> Trunking	10037 A	BR	20
	3700 Series Adapter for <b>32x16</b> Trunking	10047 A	BR	20
	3700 Series Adapter for <b>40x12,5</b> Trunking	10057 A	BR	20
	3700 Series Adapter for <b>40x16</b> Trunking	10067 A	BR	10
	3700 Series Adapter for <b>60x16</b> Trunking	10077 A	BR	10
	3700 Series Adapter for <b>110x20</b> Skirt Trunking	10107 A	BR	4
	3700 Series Adapter for <b>75x20</b> Trunking	10147 A	BR	10

■ **A** - Accessory.

■ **BR** - White.

■ See **10 Series** - Cable-trunkings for Electrical and Telecommunications Installations - Miniature Cable-trunkings (from page 114 to 117) and Skirt Cable-trunkings (page 118).