

Single Pole Switch

BR - White









The **47 Series** was designed to be used in **surface mounting electrical installations** together with **the system of Cable-trunkings of the 10 Series**.

It is a harmonic solution to surface installations in a wide variety of places like houses, offices, schools, laboratories, vans, workshops, etc..








The **47 Series** has a set of accessories designed to be **mounted in horizontal and vertical beside or over the cable-trunkings** of the 10 Series.

It is produced in **White** colour (RAL 9003) and it has a complete set of 36 basic functions.





CONTROL DEVICES (Semi-assembled with Frame and Rocker)

| | | Ref. | Colour | Box (Un) |
|---|--|---------|--------|----------|
|  | Single Pole Switch 10AX - 250V~ | 47011 S | BR | 10 |
|  | Single Pole Switch with Orienting Light 10AX - 250V~ ■ To control electronic energy-saving lamps, we recommend the use of capacitors of 0,15μF 275V~ connected in parallel to the load to avoid the blinking in the lamp when the contact is open. | 47012 S | BR | 10 |
|  | Single Pole Switch with Pilot Lamp 10AX - 250V~ | 47013 S | BR | 10 |
|  | Two Circuits Switch 10AX - 250V~ | 47061 S | BR | 10 |
|  | Two-way Switch 10AX - 250V~ | 47071 S | BR | 10 |
|  | Two-way Switch with Orienting Light 10AX - 250V~ ■ To control electronic energy-saving lamps, we recommend the use of capacitors of 0,15μF 275V~ connected in parallel to the load to avoid the blinking in the lamp when the contact is open. | 47072 S | BR | 10 |
|  | Two-way Switch with Pilot Lamp 10AX - 250V~ | 47073 S | BR | 10 |
|  | Double Two-way Switch 10AX - 250V~ | 47101 S | BR | 10 |





CONTROL DEVICES (Semi-assembled with Frame and Rocker)

| | | Ref. | Colour | Box (Un) |
|---|---|---------|--------|-------------|
|  | Intermediate Switch 10A - 250V~ | 47051 S | BR | 10 |
|  | Intermediate Switch with Orienting Light 10AX - 250V~ ■ To control electronic energy-saving lamps, we recommend the use of capacitors of 0,15μF 275V~ connected in parallel to the load to avoid the blinking in the lamp when the contact is open. | 47052 S | BR | 10 |
|  | Rocker Push-button 10A - 250V~ | 47151 S | BR | 10 |
|  | Rocker Push-button Switch with Orienting Light (250V) 10AX - 250V~ | 47152 S | BR | 10 |
|  | Rocker Push-button Switch with Identification (250V) 10AX - 250V~ | 47155 S | BR | 10 |
|  | Venetian Switch 10A - 250V~ ■ Switch function. ■ Electrical and Mechanical Blockade against the appearance of two simultaneous orders. ■ Toggles automatically one rocker when the other is pressed. | 47290 S | BR | 10 |
|  | Venetian Double Push-button 10A - 250V~ ■ Push-button function. ■ Electrical and Mechanical Blockade against the appearance of two simultaneous orders. | 47281 S | BR | 10 |

DATA SOCKETS (Semi-assembled with Frame)

| | | Ref. | Colour | Box (Un) |
|---|---|---------|--------|----------|
|  | Single RJ45 Cat. 6 UTP Computer Socket | 47455 S | BR | 1 |
|  | Single RJ45 Cat. 6 STP Computer Socket | 47445 S | BR | 1 |
|  | Single RJ45 Cat. 5e UTP Computer Socket | 47453 S | BR | 1 |
|  | Single RJ45 Cat. 5e STP Computer Socket | 47443 S | BR | 1 |

TELEPHONE SOCKETS (Semi-assembled with Frame)

| | | Ref. | Colour | Box (Un) |
|---|---------------------------------|---------|--------|----------|
| 50V — 70V~ | | | | |
|  | Telephone Socket (RITA) | 47251 S | BR | 10 |
|  | Telephone Socket (4 Conductors) | 47252 S | BR | 10 |
|  | Telephone Socket (6 Conductors) | 47253 S | BR | 10 |
| 8 contacts | | | | |
|  | T8 French Telephone Socket | 47411 S | BR | 10 |

RADIO, TELEVISION AND SATELLITE SOCKETS (Semi-assembled with Frame)

| Ref. | Colour | Box (Un) |
|------|--------|----------|
|------|--------|----------|

Radio and Television Sockets



Equalized R - TV Socket for Star Connection (Terminal type)

- Coaxial Connector \varnothing 9,5;
- 4 - 862 MHz;
- Insertion Losses: \leq 0,5dB.

47531 S

BR

10



Equalized R - TV Socket for Series Connection (Crossover type)

- Coaxial Connector \varnothing 9,5;
- 4 - 862 MHz;
- Insertion Losses: \leq 6dB;
- Flow \leq 2dB.

47532 S

BR

10

Radio, Television and Satellite Sockets



R TV - SAT Socket for Star Connection

- Coaxial Connector \varnothing 9,5;
- 4 - 470 MHz;
- Insertion Losses: \leq 1dB;
- 470 - 822 MHz;
- Insertion Losses: \leq 2dB;
- 822 - 862 MHz;
- Insertion Losses: \leq 6dB;
- Current Flow: 500mA.

47550 S

BR

10



Coaxial F Computer Socket

47431 S

BR

1


ENERGY SOCKETS (Semi-assembled with Cover)

| | | Ref. | Colour | Box (Un) |
|--|--|---------|----------|-------------|
| | Safety Earth Socket (Schuko Type) 16A - 250V~ | 47132 S | BR LR VM | 10 |
| | Earth Socket (Schuko Type) 16A - 250V~ | 47131 S | BR LR VM | 10 |
| | Safety Single Phase Socket 16A - 250V~ | 47122 S | BR | 10 |
| | Single Phase Socket 16A - 250V~ | 47121 S | BR | 10 |
| | Safety Earth Socket (French Type) 16A - 250V~ | 47112 S | BR | 10 |









OTHER PRODUCTS (Semi-assembled with Cover)

| | | Ref. | Colour | Box (Un) |
|--|--|----------|-------------|-------------|
| | Wall Rose ■ Without Connectors. | 47170 S | BR | 10 |
| | Junction Box ■ 4xx2,5mm². | 47201 S | BR | 10 |
| | Pilot Light ■ Max. 5W / 250V~ (E14). ■ To be used with Lamp Ref. 81012 (page 158). | (47360 S | BI BJ BV BM | 2 |
| | Stereo Music Socket ■ Connector DIN 41529. | 47221 S | BR | 10 |



ACCESSORY FOR SURFACE MOUNTING

| | | Ref. | Colour | Box (Un) |
|---|----------------------------|---------|--------|----------|
|  | Flush Mounting Box 60x60mm | 47993 A | BR | 10 |

ADAPTERS FOR 10 SERIES TRUNKINGS

| | | Ref. | Colour | Box (Un) |
|---|---|---------|--------|----------|
| For Lateral Mounting | | | | |
|  | 47 Series Lateral Adapter for 12x7 Trunking | 10018 A | BR | 10 |
|  | 47 Series Lateral Adapter for 16x10 Trunking | 10028 A | BR | 10 |
|  | 47 Series Lateral Adapter for 20x12,5 Trunking | 10038 A | BR | 10 |
|  | 47 Series Lateral Adapter for 32x16 Trunking | 10048 A | BR | 10 |
|  | 47 Series Lateral Adapter for 40x12,5 Trunking | 10058 A | BR | 10 |
|  | 47 Series Lateral Adapter for 40x16 Trunking | 10068 A | BR | 10 |
|  | 47 Series Lateral Adapter for 60x16 Trunking | 10078 A | BR | 10 |
|  | 47 Series Lateral Adapter for 75x20 Trunking | 10148 A | BR | 10 |

For Frontal Mounting

| | | | | |
|---|---|---------|----|----|
|  | 47 Series Frontal Adapter for 60x16 Trunking | 10079 A | BR | 10 |
|  | 47 Series Frontal Adapter for 75x20 Trunking | 10149 A | BR | 10 |

■ A - Accessory.

■ BR - White.

■ See **10 Series** - Cable-trunkings for Electrical and Telecommunications Installations - Miniature Cable-trunkings (from page 114 to 117).